


GN

GTO2 X-alps Riser: User Manual

The GTO2 can be fitted with dynema riser's for maximum weight efficiency, 320g lighter than the Kevlar risers. The riser uses newly designed soft shackles for maximum strength and minimum weight.



GTO2 X-alps Riser: Soft Shackle









Pass the Soft Shackle through the riser, then through the elastic.

Slide the elastic onto the riser.

6

Pass through the wing lines.

Pass through 2 times.



Make a loop and pass the knot through the loop.



WARNING: If not connected correctly the Soft Shackle may fail.

NOTE: It is the pilot's responsibility to check compatibility and proper installation.

Max Breaking Load: 9777 N (997kg)

Slide the elastic off the riser and over the soft shackle.

v.1.0, 04/2015